

Report
**Detection of the anti-bacterial effectivity of the device
 “ionisan Plus, based on Ion-Generator Awions AW-D6”
 against Bacteria: strain *Enterococcus faecium*.**

Summary of results

The testing performed with gram-positive bacteria, strain *Enterococcus faecium* showed after 30 minutes of exposure under dry conditions a Log-Reduction-Factor of under the conditions of this test.

Test Species	Reduction Rate %	Log-Reduction
<i>Enterococcus faecium</i>	> 99.999	> 5.81 (30min)

Aim of Investigation

Detection of reduction rate of Bacteria: strain *Enterococcus faecium* in a 30 minutes dry-exposition on glass cover slides.

Material & Methods

Target-Species

Bacteria

- *Enterococcus faecium* DSM 2146 (gram positive)
- Quantification method:
 - Linear dilution series, spread plate method
 - Slanetz-Agar
 - Incubation: 48h resp. 72h at 37°C
- Application of bacteria:
 - Dry-Exposition:
 - 50µl each parallel on glass cover slides, application as 10 single spots
 - Drying at room temperature, 30min at 36°C.
 - Exposition at room temperature (1.5m³-chamber (closed), after pre-conditioning by running the device at level “1” for 30 minutes.
 - Exposition for 30 min (21.6° to 21.7 °C // 45.6% to 47.0% RH)
 - Resuspension after exposition in 400µl NaCl_{phys.}
 - Controls, Dry-Exposition
 - 50µl each parallel on glass cover slides, application as 10 single spots
 - Drying at room temperature, 30min at 36°C.
 - Exposition at room temperature (same room, in a separate closed small box)
 - Exposition for 30 min
 - Resuspension after exposition in 400µl NaCl_{phys.}
 - Parallels
 - each run, each control: 3-fold
 - Date of test performance:
 - 28/04/2021

Results

Tab. 1: Overview on results, target species *Enterococcus faecium*

Test	Bacteria [CFU*/ml] <i>Enterococcus faecium</i>	%-Reduction
Test 1	<10	
Test 2	11	
Test 3	<10	
Mean Value Standard Deviation	9.67 x 10⁰ (Log 0.985) 1.16 x 10⁰	>99.99985 (>Log 5,814)
Control 1	7500000	
Control 2	4500000	
Control 3	6900000	
Mean Value Standard Deviation	6.30 x 10⁶ (Log 6.799) 1.59 x 10⁶	Reference value

*CFU = colony forming units

Based on the generated mean values, the reduction rate of the applied bacteria in comparison to the initial bacteria concentration is >99.999 % under the conditions of this testing. The Log-Reduction Factor (RF) is >5.81.

Yours sincerely

SGS INSTITUT FRESENIUS GmbH



i.V. Dr. Ralph Weyandt
Innovation Manager BioServices



i.V. Dr. Ella Allerdings
Lab Leader BioServices

- End of test report -

This document is issued by the Company subject to its General Conditions of Service (www.sgsgroup.de/agb). Attention is drawn to the limitations of liability, indemnification and jurisdictional issues established therein.

This document is an original. If the document is submitted digitally, it is to be treated as an original within the meaning of UCP 600.

Any holder of this document is advised that information contained hereon reflects the Company's findings at the time of its intervention only and within the limits of client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction from exercising all their rights and obligations under the transaction documents. Any unauthorized alteration, forgery or falsification of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law.